

	ltem	Part N	lame	QTY	Description	on	ltem	Part Name	QTY	Description	
	1	Billet G	rille	1	Aluminum		5	Flat Washers	2	1/4 ″	
Parts List	st 2	'L' Tabs		2	2		6	Lock Washers	2	1/4 ″	
	3	Hex Bolts		2			7	Hex Bolt	1	M6×20	
	4	Nuts		2	1/4″-20						
stall No	otes: Ov	erlay	$\checkmark$	Repla	cement ×	] D	orill 🛛 🗙	Cut ×			
Step	Description							illustration			
1	Identify the grille & hardware with parts list.								8		
	Remove th							w remove the fastener ove the grille shell from			
ן ר	Unfasten th The diagra	m below	is a vie	ew from	the front, as if y	ou wer	e standir	ng in front of the vehicle the billet firmly in pl	cle. Test fi	t the billet behind	
3 c	Unfasten th The diagra bumper. Th and down to core suppo	m below ne tabs v until the l ort. Do no	is a vie velded t billet sits bt remov	ew from owards t s snug to ve the tra	the front, as if y he center of the the bumper. Ho uns cooler line h	ou wer billet a bid the b ex bolt	e standir are to kee billet in pla on the d	ng in front of the vehic	cle. Test fi lace. Benc . Remove 'L' tabs	t the billet behind I the brackets forv the hex bolts from to the billet and o	
3 c	Unfasten th The diagra bumper. Th and down u core support support as	m below ne tabs v until the l ort. Do no shown.	is a vie velded t billet sits bt remov	ew from owards t s snug to ve the tra	the front, as if y he center of the the bumper. Ho uns cooler line h	ou wer billet a bid the b ex bolt	e standir are to kee billet in pla on the d	ng in front of the vehic p the billet firmly in pl ace with masking tape river side. Attach the on the driver side with	cle. Test fi lace. Benc . Remove 'L' tabs	t the billet behind the brackets forv the hex bolts from to the billet and o hex bolt. Tighten	
3 3 5 7	Unfasten th The diagra bumper. Th and down to core support support as hardware.	m below ne tabs v until the l ort. Do no shown.	is a vie velded t pillet sits ot remov The long	ew from owards t s snug to ve the tra ger brack	the front, as if y he center of the the bumper. Ho ans cooler line h tet attaches to th NOT REMOVE T	you wer e billet a bid the b ex bolt ne core	e standir are to kee pillet in pla on the di support of	ng in front of the vehic ep the billet firmly in pl ace with masking tape river side. Attach the on the driver side with	cle. Test fi lace. Benc . Remove 'L' tabs the 10mm	t the billet behind the brackets forv the hex bolts from to the billet and o hex bolt. Tighten	
3 ( 5 N	Unfasten th The diagra bumper. Th and down to core support support as hardware.	m below ne tabs v until the l ort. Do no shown.	ris a vie velded t billet sits ot remov The long	ew from owards t s snug to ve the tra ger brack	the front, as if y he center of the the bumper. Ho ans cooler line h tet attaches to th NOT REMOVE T	you wer e billet a bid the b ex bolt ne core	ers.but do	ng in front of the vehic ep the billet firmly in pl ace with masking tape river side. Attach the on the driver side with	cle. Test fi lace. Benc . Remove 'L' tabs the 10mm	t the billet behind the brackets forv the hex bolts from to the billet and o hex bolt. Tighten	

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!