



PATENT PRODUCT

Grille Installation Instruction

Rev. 190401

Part#	GR01FFD82 C/J/S	<i>Application</i>	For 2007-2014 Cadillac Escalade Not Fit ESV Platinum And Hybrid Models Without Tow hook
--------------	--------------------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	2	Stainless steel	3	Screws	4	8# × 3"
	2	J Hooks	4		4	U clip	4	8#

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Install the U-Nuts on the J-hooks.	
4	Insert the 8# screws through the weld tab holes on the billet grille from front side. And secure the J-Hooks (with U-Nuts) to the screws.	
5	Center the billet grille (with screws, J-Hooks) onto the OEM grille. Insert the J-Hooks to the rear of the OEM grille through the gaps on OEM grille. Secure the billet grille onto the OEM grille using the hooks & screws.	
6	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
7	Reinstall the black plastic cover which was removed in step 2.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!