




# Grille Installation Instruction

Rev. 150116

Part#	GR01HFH14H	Application	95-02 Cadillac Ei Dorado Main Upper
-------	------------	-------------	-------------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	3	Phillip Screws	6	#8 × 3/4
	2	Flat Nut	6	#8				

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	The grille shell has a center that must be removed. Separate the center from the grille shell. Unfasten the four molded clips along the top and bottom. There are four vertical bars in the center of the grille shell. Apply a light coat of black spray paint if these bars are painted.	N/A
4	Test fit the billet into the opening. The mounting tabs align with the plastic molded to the grille. It may be necessary to slightly bend the brackets so they sit against the plastic correctly. Use a pen to mark the mounting holes. Drill a 1/8" hole at each tab. Use the #8 screws and flat nuts to secure the billet to the grille shell.	N/A
5	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	N/A
6	Re-Install the grille shell assembly back onto the vehicle.	N/A
7	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!