



# PATENT PRODUCT Grille Installation Instruction

Rev. 20200601

<b>Part#</b>	A86814C&J&S	<b>Application</b>	For 1995-2002 Cadillac EL Dorado
--------------	-------------	--------------------	----------------------------------

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
<b>Parts List</b>	#1	Billet Grille	1	Stainless Steel	#3	Phillip Screws	6	#8x3/4
	#2	Flat Nut	6	8#				

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional: pop hood, remove the black plastic cover (on top of OEM grille) from vehicle. If you are still unable to access the rear, remove the grille shell according to factory manual.	
3	Hold the billet grille against the OEM grille shell, center and mark holes for drilling. Remove billet grille and drill holes according to your mark, (Drill a 1/8" hole at each tab).	
4	Thread a screw in each nut welded to the grille. Now thread a nut on each screw.	
5	Make sure the insert is centered and tighten the hardware.	
6	Reinstall the plastic shroud with the fasteners removed in Step 2.	
7	Installation completed.	

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!