

## Grille Installation Instruction

Rev. 180901

Part# GR01IEC66S/K Application For 2002-2006 Cadillac Escalade

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	3	3M Double-Sided Tape	1	
	2	(R2) Pop Rivets	5	1/8×1/2"				

Install Notes: Overlay  $\times$  Replacement  $\sqrt{}$  Drill  $\times$  Cut  $\sqrt{}$ 

	Tistali Notes. Overlay A Replacement T Dilli A Cut T						
Step	Description	illustration					
1	Identify the grille & hardware with parts list.						
2	Open the hood and remove all of the stock black plastic rivets across the radiator cover. Pry up the center of the rivet with a flat head screwdriver and then pull out the whole rivet. Save the rivets for reinstalling the grille shell.						
3	Loosen and remove the bolt at the top center of the grille shell. Pop out each of the top corner snaps using a flat head screwdriver.	Top View  Front of Vehicle Grille Shell					
4	Carefully pull the grille shell upward. Use a die grinder to remove the plastic bars by cutting them off where they meet the plastic lip as indicated below.						
5	Now cut away the side plastic where the horizontal bars meet up with the lip. Be sure to leave the chrome border for the rough cut indicated by the arrows in the diagram.	Chrome Ring					
6	Use an angle grinder to gradually sand down the chrome ring a little at a time until the chrome ring is completely removed. Caution: Do not damage the painted edge of the grille shell!	Rough Cut Chrome Ring					
7	corner and one on each of the bottom mounting tabs. Ca	d rivet into place with the hardware provided. One rivet in each top arefully pry off the stock cadillac emblem from the stock grille shell. the stock emblem and press it firmly onto the billet grille. Reinstall					
8	Installation completed!!!						

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!