

Part#	GR03DEG17 A/H	Application	<i>For 2002-2006 Chevy Avalanche Without Body Cladding/2003-2005 Chevy Silverado 1500 /2003-2005 Chevy Silverado 1500 SS /2003-2004 Chevy Silverado 2500 /2003-2004 Chevy Silverado 3500</i>
--------------	--------------------------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Grille	2	Stainless steel	3	Nylon Lock Nuts	11	0.138-32
2	Studs	11	0.138-32×2 "	4	Flat Tabs	11		

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Thread a stud in each nut welded to the grille. From the rear, place a tab on each screw. Now thread a nut on each screw.	
4	Make sure the grille is centered and tighten the fasteners, but do not over-tighten.	
5	Reinstall the black plastic cover which was removed in step 2.	
6	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!