



# Grille Installation Instruction

Rev. 190116

<b>Part#</b>	C65249C/S/ J	<b>Application</b>	For 1982-1987 Chevy Camaro Z28
--------------	-----------------	--------------------	--------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	3	Counter Sunk Screws	4	8# × 1 "
	2	U- Clip Nuts	4	8#				

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	Put the grille on the factory shell, and drill the bolt hole position based on the tabs welded on sheet grille.	N/A
4	Place screws through tabs welded on sheet grille.	N/A
5	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.	N/A
6	Attach a u-clip nut on the end of each bolt. Push the u-clip nut inside of factory shell's bolt hole, Tighten u-clip nut.	N/A
7	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	N/A
8	Reinstall the black plastic cover which was removed in step 2.	N/A
9	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!