



PATENT PRODUCT

Grille Installation Instruction

Rev. 190801

Part#	GR03FEC06 C/J/S	<i>Application</i>	For 2007-2007 Chevy Silverado 2500 HD Classic Style/2005-2006 Chevy Silverado 3500 /2006-2006 Chevy Silverado 1500 HD /2006-2006 Chevy Silverado 1500 SS /2007-2007 Chevy Silverado 3500 Classic Style/2006-2006 Chevy Silverado 1500 /2005-2006 Chevy Silverado 2500 HD /2007-2007 Chevy Silverado 1500 Classic Style
--------------	--------------------	--------------------	---

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	2	Stainless steel	3	Truss Head Screws	6	6-32×2"
	2	Lock Nuts	6	6-32	4	Flange Brackets	6	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the black plastic cover (on top of grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Identify the billet inserts and hardware from the parts list. Test fit each into the openings.	
4	Place the lower billet insert in the lower opening of the factory grille. Hold the billet in place and insert a screw in each of the mounting brackets welded to the rear of the insert. Starting in the center; install a 6" flange bracket (with the bent edges facing forward) ,washer and lock nuts so the billet is held firmly in place (do not over tighten).	
5	Repeat the installation of the upper insert as in Step 2 with the 6" flange brackets. Re-install the black plastic cover back on the vehicle.	
6	Installation completed.	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!