




# Grille Installation Instruction

Rev. 150116

Part#	GR03FEC29H	Application	01~06 Chevy Avalanche - With Cladding Billet Grille
-------	------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	2	Aluminum	3	Truss Head Screws	8	10# × 2 "
	2	Clip Nuts	8	10-24				

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Place screws through the welded aluminum tabs on the grille, and attach a clip nut on the end of each screw.	
4	Hold the billet insert up to the opening of the factory shell, make sure that it is centered in the grille shell, and push in the clip nut past the factory grille honey combo.	
5	Turn the clip nut so that it is vertical, and tighten.	
6	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	
7	Now you can install the lower grille using the same steps as above.	
8	Reinstall the black plastic cover which was removed in step 2.	
9	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!