

## Grille Installation Instruction

Rev. 180401

Part#	GR03FEG01V	Applica	For 1999-2002 Chevy Silverado 1500/1500HD / 2000-2006 Chevy Suburban / 2000-2006 Chevy Tahoe / 1999-2000 Chevy Silverado 2500/2500HD/3500

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	2	Aluminum	3	Truss Head Screws	8	6-32×1.5″
	2	Toggle Nuts	8	6#				

Install I	Notes: Overlay	Drill × Cut ×				
Step	Description	illustration				
1	Identify the grille & hardware with parts list.					
2	Remove grilles from the box and identify the top grille from the bottom grille.	N/A				
3	Place screws through the welded aluminum tabs on the grille, and attach a toggle nut on the end of each bolt.	N/A				
4	Hold the billet insert up to the opening of the factory shell, make sure that it is centered in the grille shell, and push in the toggle nut past the factory grille honeycomb.	N/A				
5	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.	N/A				
6	Reinstall the black plastic cover which was removed in step 2.	N/A				
7	Installation completed!!!	N/A				

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!