Grille Installation Instruction												Rev. 180801	
Part#	GR03FEG35A/H			Application			For 1994-1999 Chevy Blazer Not For S-10 (8 Bars)/ 1994-1999 Chevy C/K Pickup Not For C2500 Single Light (8 Bars)/ 1994-1999 Chevy Suburban / Tahoe (8 Bars)						
	lt	Item Part Nam			ne	QTY Description			ltem	Part Name	QTY	Description	
Parts L	ist	st 1 Billet Grille				2	Alumin	um	3	Screws	8	8×1 1/4″	
		2 Flat Tabs				4			4	U- Clip Nuts	8	8#	
Install N	Notes	lotes: Overlay $\checkmark$				Replacement ×			orill ×	Cut ×			
Step	Step Description								illustration				
1	Identify the grille & hardware with parts list. NOTE: The upper grille looks narrower.												
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.												
3	Slip the supplied "U" nut onto the grille backing bracket as shown.(Fig 1)												
4	Insert the screw through the front side of the grille and attach bracket on the back side as shown.(Fig 2)												
5	Insert the grille into opening and secure screw from the front side. (Fig 3)												
$[Fig 1] \qquad $													
7		Reinstall the black plastic cover which was removed in step 2.											
8	Installation completed!!!												

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!