

PN: C65741

Hardware	4 -- Flange Brackets	4 -- 8×1 1/4" Truss Head Tapping Screws	4 -- Flat Nuts
----------	----------------------	---	----------------

NOTE: Instruction for billet grille also applies to stainless steel grille.

Step	Installation operation	Instruction
1	Remove the OEM grille from vehicle.	 <p>OEM grille</p>
2	Remove the chrome shell from the OEM grille.	 <p>Chrome shell has been removed</p>
3	Place the billet grille on the OEM grille, and fasten the billet grille with screws, nuts and brackets through the welded tabs.	 <p>4 welded tabs</p> <p>Screw (with nut and bracket on real)</p>
4	Re-install the OEM grille (with the billet grille).	 <p>OEM grille (with billet grille)</p>
	Installation completed!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!