



PATENT PRODUCT




Grille Installation Instruction

Rev. 190901

Part#	GR03FEG43 C/S/J	<i>Application</i>	For 2006-2013 Chevy Impala /2006-2007 Chevy Monte Carlo /2014-2016 Chevy Impala Limited Model Only
--------------	--------------------	--------------------	---

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	2	Stainless steel	3	Bolt	4	6-32x1 .5"
	2	Kep Nuts	4	6-32	4	Tabs	4	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the grille shell from the vehicle and save all hardware as it will be reused later.	
3	Hold the grille against the OEM grille shell, and make sure that it is centered. Place screws through welded aluminum tabs on front of the grille.	
4	Secure the billet grilles to the factory grille shell using the tabs and kep nuts. Do not over tighten.	
5	Reinstall the factory grille shell using the hardware saved from step 2.	
6	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!