

## Grille Installation Instruction

Rev. 190901

Part#	GR03FEG43	Application	For 2006-2013 Chevy Impala /2006-2007 Chevy Monte
	A/H		For 2006-2013 Chevy Impala /2006-2007 Chevy Monte Carlo /2014-2016 Chevy Impala Limited Model Only

		Item	Part Name	QTY	Description	Item	Part Name		QTY	Description		
Parts L	.ist	1	Billet Grille	2	Aluminum	3	Fully Threaded Studs	;	4	10-24x1 1/4"		
		2	Kep Nuts	4	10-24	4	Tabs		4			
Install Notes: Overlay  Replacement ×						Drill	× Cut ×					
Step	Description					illustration						
1	Identify the grille & hardware with parts list.											
2	Remove the grille shell from the vehicle and save all hardware as it will be reused later.											
3	Install the fully threaded studs into the threaded holes in the backside of each billet.											
4	Center each billet grille into the factory grille shell opening.											
5	Place a tab over each of the fully threaded studs.											
6	Secure the billet grilles to the factory grille shell using the kep nuts. Do not over tighten.											
7	Reinstall the factory grille shell using the hardware saved from step 2.											
8	Installation completed!!!											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!