


<b>Part#</b>	GR03FEG47V/E	<b>Application</b>	<b>For 2004-2012 Chevy Colorado Not For Extreme</b>
--------------	--------------	--------------------	---

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
<b>Parts List</b>	1	Billet Grille	2	Aluminum	3	Truss Head Screws	6	6 -32×1.5"
	2	Toggle Nuts	6	6#				

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Place screws through the welded aluminum tabs on the grille, and attach a toggle nut on the end of each bolt.	
4	Hold the billet insert up to the opening of the factory shell, make sure that it is centered in the grille shell, and push in the toggle nut past the factory grille honeycomb.	
5	Turn the toggle nut so that it is vertical, and tighten. But not over-tighten!	
6	Repeat steps four and five for the remaining five welded tabs on the billet grille.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!