

Grille Installation Instruction

Part#	GR03FEG66V Application			ation	For 2007-2013 Chevy Silverado 1500 Main Upper										
		ltem	Part	Name	QTY	Y Descript		ion Iter		ו	Part Name		QTY	Description	
Parts L	ist 1		Billet Grille		2	Aluminum			3	Т	Truss Head Screws		10	6-32×1 1/2″	
		2 Toggle		Nuts	10	6#									
Install N	lote	s: Ov	erlay	√ R	eplacer	placement ×		[Drill [×	Cut	×			
Step	Description							illustration							
1	Identify the grille & hardware with parts list.														
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.														
3	Center the billet grille into the opening of the factory grille shell. Secure the Screws to the holes on the front of the grille. Be sure the Screws are through the OEM grille shell.														
4	Secure billet grille using the Toggle nuts from the back side of the OEM grille shell.							A R W W					(10) S (10)Tc	crews oggle Nuts	
5	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.														
6	Reii	nstall th	e black p	lastic cover	which w	as rem	oved in	step	02.						
7	Inst	Installation completed!!!													

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!