



# PATENT PRODUCT


## Grille Installation Instruction

Rev. 190601

<b>Part#</b>	GR03FEG67 C/J/S	<b>Application</b>	<b>For 2007-2013 Chevy Silverado 1500</b>
--------------	--------------------	--------------------	---

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
<b>Parts List</b>	1	Billet Grille	1	Stainless steel	3	Screws	4	8# × 3 "
	2	U- Clip Nuts	4	8#	4	Powder Coated Universal Brackets	4	

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Hold the billet grille against the OEM grille shell, center and mark holes for drilling. Remove billet grille and drill holes according to your mark. Place screws through the welded aluminum tabs on the grille. Hold the billet grille up to the opening of the factory shell.	
4	Place the powder coated brackets over the screws and hold in place using the U-Clip nuts provided.	
5	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!