


Part#	GR03FEG68J	Application	For 2006-2010 Chevy Corvette C6
-------	------------	-------------	---------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	4	Truss Head Screws	2	8# 3 "
	2	Truss Head Screws	2	8# 2 "	5	Powder Coated S-Brackets	4	
	3	U- Nuts	4	8#				

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the plastic filler panel from the underside of the front bumper. This will allow access to the backside of the bumper.	N/A
3	Install the fully threaded studs to the threaded holes in the backside of the billet grille. Attach the 3 " studs to the top, and the 2 " studs to the lower tabs.	N/A
4	Place the billet grille into the bumper opening and center to your liking.	N/A
5	Once the billet grille is centered to your liking place the powder coated s-brackets over the fully threaded studs and attach them to the edge of the bumper.	N/A
6	Holding the billet grille centered secure it to the vehicle using the k-lock nuts.	N/A
7	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.	N/A
8	Reinstall the black plastic cover which was removed in step 2.	N/A
9	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!