


Part#	GR03FEG74A/H	Application	<b>For 2007-2010 Chevy Silverado 3500 HD /2007-2010 Chevy Silverado 2500 HD</b>
-------	--------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	2	Aluminum	4	Flange Brackets	2	
	2	Flat Tabs	4		5	U- Clip Nuts	12	8#
	3	Flange Brackets	4		6	Truss Head Tapping Screws	12	8×2"

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Place one screw through each of the welded tabs on the billet grille. Place a U-clip nut over each of the holes on the tabs.	
4	Where the screws come through the grille shell, place a tab in align with the screw and tighten.	
5	Tighten each of the screws evenly so as not to put the grille in a bind and not to make it go off center. DO NOT OVER TIGHTEN SCREWS.	
6	Repeat steps 3 -5 for the bottom grille.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!