



PATENT PRODUCT Grille Installation Instruction

Rev. 20200901

Part#	C65967C&J&S	Application	For 2014-2015 Chevy Camaro SS
--------------	-------------	--------------------	-------------------------------

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	#1	Billet Grille	1	Stainless Steel	#3	Washers	5	
	#2	Bolts	5	10#-24x1/2"	#4	Nuts	5	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional: pop hood, remove the black plastic cover (on top of OEM grille) from vehicle. If you are still unable to access the rear, remove the grille shell according to factory manual.	
3	Thread a Bolt in each nut welded to the grille. From the rear, place a washer on each Bolt. Now thread a Nut on each Bolt.	
4	Make sure the insert is centered and tighten the hardware.	
5	Reinstall the plastic shroud with the fasteners removed in Step 2.	
6	Installation completed.	

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!