

Part#	GR03FEI90 F/W	Application	For 2014-2015 Chevy Silverado 1500
-------	------------------	-------------	------------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billets	6	Aluminum	5	# of billets	6	
	2	Nylon Lock Nuts	2	6-32	6	# of rivets	20	
	3	Black Fender Washers	2		7	# of tabs	6	
	4	Stud	2	6-32×2"	8	Allen Key	1	
					9	Wrench	1	

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list. Assemble billet grille as shown.	
2	Test fit the grille in the factory bumper opening. On the backside of the mesh grille are two threaded studs. Note where they make contact with the plastic in the factory bumper opening and mark the point of contact.	
3	Now drill a 1/4" hole through the plastic in the factory bumper opening where you made the contact marks. Now insert the grille into the factory bumper opening with the threaded studs on the grille going through the holes that you just drilled.	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



# Grille Installation Instruction

Rev. 191101

Part#	GR03FEI90 F/W	Application	<b>For 2014-2015 Chevy Silverado 1500</b>
4	Thread a stud in each nut welded to the grille. Hold the grille against the OEM grille shell, be sure the bolts are through the OEM grille shell.		
5	From underneath the vehicle reach up behind the mesh grille and locate the two threaded studs protruding through the plastic. You may need to unclip the rubber splash guard on the bottom of the vehicle to reach the threaded studs. Place the black washers and nylon lock nuts on the threaded studs and tighten the lock nuts.		
6	Replace the clips on the splash guard if you removed them.		
7	Installation completed!!!		

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!