

PATENT PRODUCT Grille Installation Instruction

Rev. 170901

Item Part Name QTY Description Item Part Name QTY 1 Billet Grille 1 Stainless steel 3 Screws 2 2 U Cip Nut 2 4 Flat Washers 2 Install Notes: Overlay ✓ Replacement × Drill ✓ Cut × Step Description illustration 1 Identify the grille & hardware with parts list. illustration 2 Insert the bumper billet into the factory bumper opening. Insert the bumper billet into the factory bumper opening. 3 Looking through the billet bars locate the 2 small black square tabs with the small hole in the center that are welded to the backside of the billet grille. With a 3/16 '' drill bit inserted through the hole in the tab make a small mark in the plastic of the factory bumper opening. 3 Now remove the billet and drill a hole through the billet grille mark. Make sure to drill the hole through the small mark in the plastic factory bumper 4 Now remove the billet and drill a hole through the small mark. Make sure to drill the hole through the small mark. Make sure to drill the hole through the small mark in the plastic factory bumper	Description 2.5 "
Step Description illustration 1 Identify the grille & hardware with parts list. Identify the grille & hardware with parts list. 2 Insert the bumper billet into the factory bumper opening. 3 Looking through the billet bars locate the 2 small black square tabs with the small hole in the center that are welded to the backside of the billet grille. With a 3/16 " drill bit inserted through the hole in the tab make a small mark in the plastic of the factory bumper opening. Now remove the billet and drill a hole through the bumper plastic where you just made the small mark. Make sure to drill the hole through the aluminum plate behind the plastic factory bumper	
1 Identify the grille & hardware with parts list. 2 Insert the bumper billet into the factory bumper opening. 3 Looking through the billet bars locate the 2 small black square tabs with the small hole in the center that are welded to the backside of the billet grill. 3 With a 3/16 " drill bit inserted through the hole in the tab make a small mark in the plastic of the factory bumper opening. A Now remove the billet and drill a hole through the bumper plastic where you just made the small mark. Make sure to drill the hole through the aluminum plate behind the plastic factory bumper	
 Insert the bumper billet into the factory bumper opening. Looking through the billet bars locate the 2 small black square tabs with the small hole in the center that are welded to the backside of the billet grille. With a 3/16 " drill bit inserted through the hole in the tab make a small mark in the plastic of the factory bumper opening. Now remove the billet and drill a hole through the bumper plastic where you just made the small mark. Make sure to drill the hole through the aluminum plate behind the plastic factory bumper 	
 Looking through the billet bars locate the 2 small black square tabs with the small hole in the center that are welded to the backside of the billet grille. With a 3/16 " drill bit inserted through the hole in the tab make a small mark in the plastic of the factory bumper opening. Now remove the billet and drill a hole through the bumper plastic where you just made the small mark. Make sure to drill the hole through the aluminum plate behind the plastic factory bumper 	
 Black square tabs with the small hole in the center that are welded to the backside of the billet grille. With a 3/16 " drill bit inserted through the hole in the tab make a small mark in the plastic of the factory bumper opening. Now remove the billet and drill a hole through the bumper plastic where you just made the small mark. Make sure to drill the hole through the aluminum plate behind the plastic factory bumper 	
bumper plastic where you just made the small mark. Make sure to drill the hole through the aluminum plate behind the plastic factory bumper	
insert. Reinsert the billet into the bumper opening and insert the two machine screws through the billet bars, the small black tab with the hole in it and the factory bumper plastic.	
5 From behind the bumper install the 1 " flat washers and the U Clip Nut and tighten. You can reach beh underneath the vehicle, you may need to unclip the rubber splash guard to gain access to the backside	
6 Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.	
7 Reinstall the black plastic cover which was removed .	
8 Installation completed!!!	

TThe instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!