

Grille Installation Instruction

Rev. 181201

Part# GR03FEI97A/H Application For 2014-2015 Chevy Camaro LT/LS With RS Package

	!	de la																
Porto L	iot	Item	Part Name		QTY	Descript Aluminum		on	Item	N 4 -	Part Name				QTY	Description		
Parts L	เรเ	2	Billet Grille		4	6-32	inum		3	IVI	Machine scre		9W		4	0-32	6-32x1 1/2	
	2 Toggle nut 4 6-32									<u> </u>		-		1				
Install Notes: Overlay V Replacement ×								Dr	ill 🗀	×		Cut	×					
Step	Description							illustration										
1	Identify the grille & hardware with parts list.																	111111
2	Take the four machine screw and insert them through the front of the billet grille bars and the small square tabs with a hole in the center that are welded to the back of the billet grille, take the four toggle wing and install them onto the machine screws.								MINISTER OF STREET				1					
3	Place the billet grille with the four screws and toggle wings installed into the bumper cover opening.																	
4	Using a flat screwdriver reach through the billet bars and spin the toggle wings horizontally so that they insert through the plastic bars in the bumper cover, while holding the toggle with the flat screwdriver use a phillips screwdriver to tighten the machine screws until the billet is secure in the vehicle bumper cover.																	
5	Rep	Replace the clips on the splash guard if you removed them.																
6	Installation completed!!!																	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!