

PATENT PRODUCT Grille Installation Instruction

Rev. 20200501

Part#	C65092C&J&S Application For 2019-U		or 2019-UP	Chevy	Camaro	o ZL1						
	Item		Part Name		QTY	•		Item #3	Part Name	QTY	Description	
Parts Li		st #1 Billet Grille #2 Bolts		rille	1 4		Stainless Steel 6-32×2"		Toggle Nuts	4	6-32	
		#Z DUILS			4	4 0-32×2						
Install Notes: Overlay V Replacement X Drill X Cut X												
Step	Description						illustration					
1	Identify the grille & hardware with parts list.											
2	Optional: pop hood, remove the black plastic cover (on top of OEM grille) from vehicle. If you are still unable to access the rear, remove the grille shell according to factory manual.											
3	Insert the Bolt into the weld tab hole from front side of the billet grille. Dicture for reference only; this is not actual grille Bolt											
4	Center the billet grille onto the OEM grille. Press & insert the toggle nuts on to the rear of the OEM grille through the gap.(Fig 2 & 3)											
Fig 2	(4) 6-32 Toggle Nuts (4) 6-32×2" Bolts Fig 3											
5	Make sure the insert is centered and tighten the hardware.											
6	Reinstall the plastic shroud with the fasteners removed in Step 2.											
7	Installation completed.											

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!