

Part#	GR03FFC18 FW	Application	For 2015-2018 Chevy Silverado 2500HD/3500HD (Not For Z71 Package and High Country Model) / 2019 Chevy Silverado 2500HD/ 3500HD Only for LTZ
-------	-----------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	2	Aluminum	4	Lock Nuts	4	10-24
	2	Studs	4	10-24x2"	5	Lock Nuts	4	6-32
	3	Studs	4	6-32x2"	6	Flat Tabs	8	

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list. Assemble billet grille as shown.	
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.	
3	Secure the stud to the threaded holes on the rear of the grille. Hold the billet insert up to the opening of the factory shell, and make sure that it is centered in the grille shell.	
4	Secure grille using the flat tabs and lock nuts from the back side of the OEM grille shell.	
5	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!