


Part#	<b>GR03FFD66H</b>	Application	<b>06~10 Chevy Trailblazer LT – Low Bumper Billet Grille</b>
-------	-------------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	5	Screws	2	#8×1"
	2	U-Nuts	2	8#	6	Nuts	2	1/4-20×3/4
	3	'L' brackets	2		7	Washers	2	1/4-20×3/4
	4	Bolts	2	1/4-20×3/4				

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Slide a u-nut onto the short end of the 'L' Brackets. Attach the other end to a pre-drilled hole in the bumper opening; use the 1/4 bolts, nuts and washers. The holes are located next to a plastic fastener on each end.	
4	Center the billet into the opening; the mounting tabs align to the 'L' brackets on top. Use the screws to secure the billet to the 'L' brackets. It may be necessary to slightly bend the 'L' brackets so the billet has the proper angle. Remove the grille and adjust the brackets if needed.	
5	Make sure the grille is centered and tighten the fasteners.but do not over-tighten.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.  
Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.  
We are not responsible for any damage caused by the installation. Thank you for choosing our product!