




# Grille Installation Instruction

Rev. 150116

Part#	GR03FFD67H	Application	<b>07-up Chevy Avalanche/Tahoe/Suburban - Bolton 2-pc Low Bumper Billet Grille</b>
-------	------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	2	Aluminum	3	Flat Nuts	6	8#
	2	Phillips Screws	6	#8 x 3/4"				

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	Center one of the grilles in place. Mark the mounting tabs to the tow hook opening. Re-center the grille. Double check the marks to the mounting tabs. Remove the billet and drill a 1/16" hole at each mark.	N/A
4	Secure billet grille using the k-lock nuts from the back side of the OEM grille shell.	N/A
5	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	N/A
6	Reinstall the black plastic cover which was removed in step 2.	N/A
7	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!