



Grille Installation Instruction

Rev. 150116

Part#	GR03FFE6 9C	Application	For 99-02 Chevrolet Silverado 00-06 Suburban / Tahoe / Avalanche Low Bumper Billet Top Pad Inset – 1 Piece (3 Bars)
-------	----------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	3	Screws	2	8# × 1.5"
	2	U-Clip Nut	2	8#	4	Tabs	2	8#

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	N/A
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	Note the four tabs on the rear of each billet. These tabs will apply pressure to the rear of the top pad to hold the billets in place. It may be necessary to slightly bend these tabs out using your hands or pliers.	N/A
4	Use masking tape around each opening if the bumper pad is painted. Place one billet with the top tabs in first; Then apply even pressure at each tab along the lower of the billet till it snaps in the bumper pad. Repeat this on the other insert.	N/A
5	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	N/A
6	Reinstall the black plastic cover which was removed in step 2.	N/A
7	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
We are not responsible for any damage caused by the installation. Thank you for choosing our product!