



# Grille Installation Instruction

Rev. 150116

<b>Part#</b>	GR03FFE88C&J&S	<b>Application</b>	For 2007-2010 Chevy Silverado 2500 HD /2007-2010 Chevy Silverado 3500 HD
--------------	----------------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	stainless steel	3	Clip Nuts	4	#8
	2	Truss Head Tapping Screws	4	#8x3"	4	Flat Tabs	4	/

**Install Notes:**
 Overlay 
 Replacement 
 Drill 
 Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. Remove the front license plate and mounting bracket from the bumper opening.	
3	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell. Center the billet grille into the bumper opening and mark and drill the mounting holes.	
4	Secure billet grille using the clip nuts and tabs from the back side of the OEM grille shell.	
5	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed.	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!