


Part#	GR03FFG38A&H	<i>Application</i>	For 2010-2015 Chevy Equinox (2012-2015 Model Need Drilling)
--------------	--------------	--------------------	--

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	2	Aluminum	3	Truss Head Screws	7	6-32 × 1.5"
	2	Toggle Nuts	7	6#				

Install Notes: Overlay Replacement Drill Cut

Step	Description	Illustration
1	Identify the grille & hardware with parts list.	
2	Optional for vehicles with black plastic cover under hood: Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.	
3	Center the billet grille into the opening of the factory grille shell. Place screws through the welded aluminum tabs on the grille. Be sure the screws are through the OEM grille shell. NOTE: For 2012-2015 models, drilling is required to install the upper piece. Hold the billet grille against the OEM grille shell, center and mark holes for drilling. Remove billet grille and drill holes according to your mark.	
4	Thread in the toggle nut from the back of OEM grille to secure the billet grille.	
5	Turn the toggle nut so that it is vertical, and tighten. But not over-tighten.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed.	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
We are not responsible for any damage caused by the installation. Thank you for choosing our product!