

Part#	GR03FFG39A	Application	2010-2012 Chevy Equinox Lower Bumper
-------	------------	-------------	--------------------------------------

Parts List	Item	QTY	Part Name	Description	Item	QTY	Part Name	Description
	1	1	Billet Grille insert	5 Billets	3	2	Speed Clips	8#
2	2	Counter Sunk Screws	8#x3/4"	4	/	/	/	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	N/A
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Center the billet grille into the opening of the factory grille shell. You need mark and drill two holes. Secure the screw to the threaded holes on the front of the grille. Be sure the screws are through the OEM grille shell.	
4	Secure billet grille using the speed clips and counter sunk screws.	
5	Make sure the billet grille is centered and tighten the fasteners.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!