


Part#	GR03FFH00A/H	Application	For 2004-2010 Chevy Colorado Xtreme
--------------	--------------	--------------------	--

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	3	Aluminum	3	Fully Threaded Studs	8	10-24×2"
	2	K-Lock Nuts	8	10-24	4	Powder Coated Brackets	8	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.	
3	Attach and secure the fully threaded studs to the back of the billet grille.	
4	Center the billet grille into the bumper openings and place the powder coated brackets over the fully threaded studs. Secure billet grille to the bumper using the K-lock nuts.	
5	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!