




Part#	GR03FFH31S	Application	<b>For 2011-2014 Chevy Silverado 2500 HD</b> <b>For 2011-2014 Chevy Silverado 3500 HD</b>
-------	------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	2	Stainless steel	3	Truss Head Screws	10	6-32 × 1.5"
	2	Flat Tabs	10		4	Flange Nuts	10	6-32

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop Hood, remove plastic shroud at the top and set fasteners aside.	N/A
3	Optional: Using factory instructions, remove the entire front grille shell.	N/A
4	Position the Billet Grille onto grille shell cavity.	N/A
5	Loosely attach the Billet Grille by holding the Flat Tabs behind factory grille shell and inserting the Screws (from the front) through the Billet Grille holes and Flat Tabs, secure them with Flange Nuts provided.	
6	Once the Billet Grille is loosely attached, center it and tighten all Screws at the same rate.	N/A
7	Reinstall the plastic shroud with the fasteners removed in Step 2.	N/A
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!