


Part#	GR03FGH6 2J	Application	For 2007-2013 Chevy Silverado 1500
-------	----------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	2	Stainless steel	3	Truss Head Screws	8	6-32×2"
	2	Toggle Nuts	8	6#				

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.	N/A
4	Secure billet grille using the Toggle nuts from the back side of the OEM grille shell.	N/A
5	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	N/A
6	Reinstall the black plastic cover which was removed in step 2.	N/A
7	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Grille Installation Instruction

Rev. 150116

Part#	GR03FGH6 2J	Application	For 2007-2013 Chevy Silverado 1500
-------	----------------	-------------	------------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	3	Screws	4	8# × 3 "
2	U- Clip Nuts	4	8#	4	Powder Coated Universal Brackets	4		

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	N/A
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Install the fully threaded studs into the threaded tabs on the backside of the billet grille.	
4	Center the billet grille into the bumper opening and mark and drill the mounting holes. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.	
5	Re-center the billet grille into the bumper opening.	
6	Place the powder coated brackets over the fully threaded studs and hold in place using the k-lock nuts provided.	
7	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	
8	Reinstall the black plastic cover which was removed in step 2.	
9	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!