



PATENT PRODUCT


Grille Installation Instruction

Rev. 200601

Part#	GR03FGI20C	<i>Application</i>	For 2006-2013 Chevy Impala /2006-2007 Chevy Monte Carlo /2014-2016 Chevy Impala Limited Model Only
--------------	------------	--------------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	5	Stainless steel	4	Bolt	4	6-32x1 .5"
	2	Kept Nuts	4	6-32	5	Tabs	4	
	3	Tapping Screw	8	8# x 1"	6	U-Clip Nut	8	8#

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	(Optional) Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Hold the grille against the OEM grille shell, and make sure that it is centered. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the grille shell.	
4	For the upper pieces, secure the billet grilles to the factory grille shell using the tabs and kept nuts. For the lower pieces, secure billet grille using the lock nuts and flat tabs from the back side of the grille shell. Do not over tighten.	
5	Reinstall the factory grille shell using the hardware saved from step 2.	
6	Installation completed.	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!