

PATENT PRODUCT Grille Installation Instruction

Rev. 20221101

| Part# | C75194T&H | | 4T&H | Applicatio | on F | For 2018-2021 Chevy Traverse | | | | | | |
|--|--|--|-----------|------------|------|------------------------------|--------------|------|-----------------|-----|-------------|--|
| | I | ltem | Part Name | | QTY | Descrip | otion | Item | Part Name | QTY | Description | |
| Parts Li | st | #1 | Mesh G | esh Grille | | Stainless Steel | | #3 | Hex Flange Nuts | 6 | #6 | |
| | | #2 Studs | | 6 | | #6x1.5"-32 | | #4 | Flat Tabs | 6 | | |
| Install Notes: Overlay \checkmark Replacement \times Drill \times Cut \times | | | | | | | | | | | | |
| Step | Description | | | | | | illustration | | | | | |
| 1 | Identify the grille & hardware with parts list. | | | | | | | | | | | |
| | Optional: pop hood, remove the black plastic cover (on top of OEM grille) from vehicle. If you are still unable to access the rear, remove the grille shell according to factory manual. | | | | | | | | | | | |
| 3 | Thread a Stud in each nut welded to the grille. From the rear, place a Tab on each Stud. Now thread a Hex Flange Nut on each Stud. | | | | | | | | | | | |
| (6) #6x1.5" Studs (6) Hex Flange Nuts (6) Flat Tabs | | | | | | | | | | | | |
| 4 | Mak | Make sure the insert is centered and tighten the hardware. | | | | | | | | | | |
| 5 | Reinstall the plastic shroud with the fasteners removed in Step 2. | | | | | | | | | | | |
| 6 | Installation completed. | | | | | | | | | | | |

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!