<b>A</b>		
	P	
AUTO PARTS SPEC	ALIST INC.	

.

Fig 4

Part#	GR03GEI95 T/HApplicationFor 2014-2015 Chevy Camaro SS/LS/LT With RS Package								Package						
		Item	Part Name Mesh Grille		ne	QTY De		Description		Item		Part Name		QTY	Description
Parts Li	ist	1			1	Stainless st		eel	3	;	Stud		4	6# × 3″	
		2	Flange nut			4	6#			4		2-holes Tab	6	4	6#
Install N	lote	s: Ov	erlay	$\checkmark$	Re	placer	nent	×	D	Drill	×	Cut	×		
Step	Description								illustration						
1	Identify the grille & hardware with parts list.														A CONTRACT OF STREET
2	Open the hood on the vehicle. Now remove the four 10mm bolts from the top of the radiator cover plate (Fig 1)														
3	Now remove six plastic pop clips that hold the radiator cover and the bumper cover together (Fig 2)														
4	Now remove the radiator cover plate (Fig 3&4) this will give you access to the rear of the factory grill.														
5	Take the two bone brackets and reach down behind the mesh grille and insert them onto the threaded studs on the back of the mesh grille. (Fig 5)														
6	Slide the tabs over the threaded studs along with the flange nuts and tighten.														
7	Reinstall the black plastic cover which was removed in step 2.														
8	Installation completed!!!														
Fig 1						Fig 2						Fig	13		

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

Fig 5