

## Grille Installation Instruction

Rev. 190101

Part#	G	19RU39CL/31/0   4000020000						016-2018 Chevy Malibu (Not for Limited Model) Upper							
		Item	Part Na	me	me QTY		Descri	ption	Item	า [	Part Name	QT	Y	Description	
Parts L	ist	1	Mesh Grill	е	2	Stainless S		Steel	3		Studs	12	2	0.138-32X 1"	
	2		Hex Flange Nuts		12 0.1		).138-32		4		Flat Tabs	12	2		
Install N	Note	es: Ov	verlay 🗸	] Re	eplacen	nen	t 🛛 ×	Dri	i <b>li</b>		Cut	×			
Step	Description								illustration						
1	Identify the grille & hardware with parts list.														
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.														
3	Hold the grille against the OEM grille shell, center and mark holes for drilling. Remove grille and drill holes according to your mark.														
4	Secure the stud to the threaded holes on the rear of the grille.Hold the grille up to the opening of the factory shell. Secure the grille using the flat tabs and hex flange nuts from the back side of the OEM grille shell.								Mark and drill 9 holes						
5	Make sure the grille is centered and tighten the fasteners.														
6	Re	install t	the black pla	stic co	ver whic	h w	as rem	oved in a	step 2						
7	Installation completed!!!														

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!