

**PN: GR03GFF74T**

**09-10 Chevy Aveo – Stainless Steel Mesh Grille**

Hardware

11-- 6-32×1" Screws

11 -- 6-32 K-Lock Nuts

11-- Flat Tabs

- (1) Remove the grille from the box. Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.
- (2) Thread a screw in each nut welded to the grille. From the rear, place a tab on each screw. Now thread a nut on each screw.
- (3) Make sure the insert is centered and tighten the hardware.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!