


Part#	GR03GGH17T	Application	2006-2013 Chevy Impala With Fog Light /2014-2016 Chevy Impala Limited Model Only With Fog Light
-------	------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	4	Stainless steel	4	Screws	6	6-32×1 1/2"
	2	Flat Tabs	15		5	Nylon Lock Nuts	15	6-32
	3	Washers	15		6	Screws	9	6-32×1"

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Start with the upper section. Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Thread a screw in each nut welded to the grille. From the rear, place a tab on each screw. Now thread a nut and a washer on each screw.	
4	Continue to the lower section. Thread a screw in each nut welded to the grille. From the rear, place a tab on each screw. Now thread a nut and a washer on each screw.	
5	Center the grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.	
6	Secure billet grille using the nuts from the back side of the OEM grille shell.	
7	Make sure the grille is centered and tighten the fasteners, but do not over-tighten.	
8	Reinstall the black plastic cover which was removed in step 2.	
9	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!