




Grille Installation Instruction


Part#	GR03HAA 02J	<i>Application</i>	For 1999-2002 Chevy Silverado 1500 For 2000-2006 Chevy Suburban For 2000-2006 Chevy Tahoe
--------------	------------------------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	2	Stainless steel	3	Truss Head Tapping Screws	10	10# × 3/4"
	2	U- Nut	10	10#	4	Flat Tabs	2	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	3 Remove the upper grille. Take off the stepped tabs from the grille, place a U-clip nut on the end of each one, and attach it to the factory grille shell. Then re-insert the billet grille into place, attaching it with the bolts and nuts provided.
4	Pull back the top grille, until the two top welded tabs of the grille are flush with the plastic in the corners, using the welded tabs on the grille as a guide, mark and drill the holes and attach with the nuts and bolts provided. You need mark and drill eight holes.	5 Remove the bottom grille and the stepped tabs. Place a U-clip nut on the end of each of the stepped tabs, and attach it to the factory grille shell.
6	Secure billet grille using the U-lock nuts from the back side of the OEM grille shell.	



7	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	N/A
8	Reinstall the black plastic cover which was removed in step 2. Installation completed!!!	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Grille Installation Instruction

Rev. 150116

Part#	GR03HAA0 2J	<i>Application</i>	For 2000-2006 Chevy Avalanche For 1999-2002 Chevy Silverado 1500 For 2000-2006 Chevy Suburban For 2000-2006 Chevy Tahoe
--------------	----------------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	3	Screws	2	8# × 1.5"
2	U-Clip Nut	2	8#	4	Tabs	2	8#	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	N/A
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	Note the four tabs on the rear of each billet. These tabs will apply pressure to the rear of the top pad to hold the billets in place. It may be necessary to slightly bend these tabs out using your hands or pliers.	N/A
4	Use masking tape around each opening if the bumper pad is painted. Place one billet with the top tabs in first; Then apply even pressure at each tab along the lower of the billet till it snaps in the bumper pad. Repeat this on the other insert.	N/A
5	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	N/A
6	Reinstall the black plastic cover which was removed in step 2.	N/A
7	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!