

## **Grille Installation Instruction**

Rev. 150116

Part# GR03HEA03H Application 2014 TOYOTA TUNDRA Hood Billet Grille

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	1	Aluminum	3	Screws	8	8×3/4"
	2	U-Clip Nuts	8	8#				

Install Notes: Overlay  $\sqrt{\phantom{a}}$  Replacement  $\times$  Drill  $\times$  Cut  $\times$ 

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Center the billet insert in the opening. Attach the grille to the van with the screws and clips provided. It may be necessary to slightly bend the brackets on the inserts on the insert to get a perfect fit.	N/A
4	Secure billet grille using the U-Clip Nuts from the back side of the OEM grille shell.	N/A
5	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.	N/A
6	Reinstall the black plastic cover which was removed in step 2.	N/A
7	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!