

7

Installation completed!!!

Grille Installation Instruction

Rev. 190501

Part#	GR03HEA06 A/H	Application	For 1995-1999 Chevy Monte Carlo
-------	------------------	-------------	---------------------------------

<u></u>												
		Item	Part Name	QTY	Description	n	Item	Part Name	QTY	Description		
Parts L	ist	1 Billet Grille		1	Aluminum		3	Screws	4	8 ×1"		
		2	U-Clip Nuts	4	8#							
Install Notes: Overlay Replacement												
Step	Description					illustration						
1	Idei	ntify the	grille & hardware wi	th parts li	st.							
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.											
3	Center the factory grille into the opening of the shell mark and drill point holes in the plastic. Slide the speed clips (it used as a U-clip nut) onto the flange sides of the shell and threaded the self-tapping into the holes by a Phillip screwdriver.											
4	Secure billet grille using the U-Clip Nuts from the back side of the OEM grille shell.											
5	Mark sure the billet grille is centered, tighten the hardware but do not over-tighten.											
6	Reinstall the black plastic cover which was removed in step 2.											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!