

## Grille Installation Instruction

Rev. 180401

Part#	GR03HEB12A/H	Application	For 2006-2011 Chevy HHR
-------	--------------	-------------	-------------------------

		Item Part N		ame QTY		Description	Item	Part Name		QTY	Description			
Parts Li	ict	1	Billet Grille		1	Aluminum	4	Fully Threaded Studs		5	1 1/4"			
Parts L	ısı	2	Kep Nuts		5		5	Truss Head Tapping Screws		3	8#			
		3	U-Nuts		3		6	Powder Coated Brackets		3				
Install Notes: Overlay X Replacement							Drill × Cut ×							
Step	Description							illustration						
1	Idei	ntify the	grille & ha	ardwai	re with p	arts list.		21 H H H						
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.													
3	Loosely attach the powder coated brackets to the upper mounting points in the factory opening using the #8 screws and U-nuts. Do not fully tighten as some adjustment may be necessary.													
4	Secure the fully threaded studs to the backside of the billet grille.													
5	Place the billet grille into the factory grille opening. The two lower fully threaded studs go directly through factory mounting points (Figure 1). The three upper fully threaded studs mount to the powder coated brackets(Figure 2) .													
6						ning and note the to the to the vehicle.	ocation	of the pov	vder coated brackets.	Remove t	he billet grille and			
7	Plac		illet grille	into th	e factory	opening, making	sure tha	t it is center	ed. Attach the k-lock n	uts to the	fully threaded			
8	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.													
9	Rei	nstall th	ne black pl	astic c	over wh	ich was removed	in step 2.							
10	Installation completed!!!													
_			. 1	:- 0	·		7	141	4 41 1.111.411 1	4 - 1	1:41 1:4			

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!