




PATENT PRODUCT Grille Installation Instruction

Rev. 20210601

Part#	C85250C&J&S	Application	For 1974-1977 Chevy Camaro
--------------	-------------	--------------------	----------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	#1	Billet Grille	1	Stainless Steel				

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional: pop hood, remove the black plastic cover (on top of OEM grille) from vehicle. If you are still unable to access the rear, remove the grille shell according to factory manual.	
3	Remove the OEM grille shell by removing the screws on 4 corners as shown in the picture. These screws are needed to install new grille.	
4	Center the billet grille into the opening front fascia. Thread the screws to the threaded holes on 4 corners of the grille. Secure billet grille to the same mounting point as the OEM grille.	
5	Make sure the insert is centered and tighten the hardware.	
6	Reinstall the plastic shroud with the fasteners removed in Step 2 .	
7	Installation completed.	

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!