

Grille Installation Instruction

Rev. 180501

Part# GR03HEB52A/H Application For 1967-1968 Chevy Camaro RS Model Billet Grille And Headlight Doors

		Item	Part Name	QTY	Descrip	tion	Item	Part Name	QTY	Description	
Parts List		1 Billet Grille		3	Aluminum		3	Screws	21	6-32×1″	
		2 Kept Nuts		21	21 6-32						
Install Notes: Overlay X Replacement							Orill _	Cut ×			
Step	Description					illustration					
1	Identify the grille & hardware with parts list.										
2	Pop Hood,remove plastic shroud at the top and set fasteners aside.										
3	Position the Billet Grille onto grille shell cavity.										
4	Make the mark on the grille shell through the billet grille holes and drill holes at these marked locations										
5	the the Gril	Billet G Screws	the billet grille and lo Grille to the grille shell s(from the front) thro s and shell holes,sect ded.	by insertugh the E	ing Billet						
6	Ond	Once the Billet Grille are loosely attached, center them and tighten all screws at the same rate.									
7	Rei	Reinstall the black plastic cover which was removed in step 2.									
8	Installation completed.										

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!