

Installation completed!!!

4

Grille Installation Instruction

Rev. 190301

Part#	G	GR03HEC02 A/H		/200 Clas	For 2003-2006 Chevy Silverado 1500 / 2500 HD / 3500 / 1500 HD /2003-2004 Chevy Silverado 2500 /2007-2007 Chevy Silverado 1500 Classic Style/ 2500 HD Classic Style/ 3500 Classic Style/2002-2006 Chevy Avalanche Without Body Cladding						
	lte	em	Part Name		QTY	Description		Item	Part Name	QTY	Description
Parts		1	Right Billet Grille		1	Aluminum		5	Flat Washers	4	1/4"
List		2	Left Billet Grille		1	Aluminum		6	Lock Washers	4	1/4"
	;	3	Hex Bolts		4	1/4"-20×3/4"		7	"Z" Bracket Tabs	2	/
	4	4	Nuts		4	1/4"-20					
Install Notes: Overlay $oxedow{ imes}$ Replacement $oxedow{ imes}$ Drill $oxedow{ imes}$ Cut $oxedow{ imes}$											
Step		Description					illustration				
1	Identi parts		he grille {	& hard	ware w	ith	=		■ ■		
2	Attach the Z brackets to the billet insert using the hardware provided. Do not tighten the hardware at this time.						Fasten with hex bolt, flat washer & nut				
3	bump enough bump the bump hardy	per of the service of	ne billet ir opening. To cover bot Align the r ory holes Fasten t provided.	he inse h openi mountin on to hem u Make	ert is loonings in the color of	ng he to he he he		<u> </u>	Fasten the grille hole on top of th hex bolt, flat was	e bump	per with

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!