

PATENT PRODUCT Grille Installation Instruction

Rev. 180401

Part# GR03HEJ08C/J Application 1973-1980 Chevy C/K Pickup / 1973-1980 Chevy Suburban / 1973-1980 GMC C/K Pickup / 1973-1980 GMC Suburban	Part#	GR03HEJ08C/J	Application	1973-1980 Chevy Suburban / 1973-1980 GMC C/K Pickup /
--	-------	--------------	-------------	--

Pari#	GROSHEJOOC/J AL			Арріісан	1973-1980 Chevy Suburban 1973-1980 GMC C/K Pickup / 1973-1980 GMC Suburban						
	ŀ	ltem	Part Name		QTY	Description	Item	Part Name	QTY	Description	
Parts L	iot	1	Billet Grille		1	Stainless steel	4	Hex Bolts	8	1/4" -20×3/4"	
Parts L	ist	2	Support Bracket-L		1		5	Kep Nuts	8	1/4" ×20	
		3	Support Bracket-R		1						
Install Notes: Overlay × Replacement √ Drill √ Cut ×											
Step	Description						illustration				
1	Identify the grille & hardware with parts list.						y.				
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.										
3	To remove the two factory vertical grille supports, it is necessary to remove two 5/16" bolts in the front of the radiator support and one on top of the support. There are three 5/16" bolts per support.					front the N/A					
4	grille the fr	shell. ront of	Secure the b	to the opening olt to the three sure the bol	aded hole	es on N/A					

Make sure the billet grille is centered and tighten 6 N/A the fasteners. Reinstall the black plastic cover which was removed 7 N/A in step 2. 8 Installation completed!!! N/A On 1973-1974 trucks it requires marking and drilling four 5/16 " diameter holes in radiator support for attachment. 9

N/A

Secure billet grille using the nuts from the back side

of the OEM grille shell.

5

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!