Grille Installation Instruction										Rev. 150116		
Part#	G	R03H 2C		Application		For 1991-1993 Chevy S-10 Blazer For 1991-1992 Chevy S-10 Pickup						
		Item	Part	Name	QTY	Description	Item		Part Name	QTY	Description	
Parts L	.ist	1	Billet	Grille	2	Stainless steel	3	Truss H	ead Tapping Screws	8	8# × 3/4 ″	
		2 Flat		lut	8	8#						
Install Notes: Overlay $\checkmark$ Replacement $\times$						cement X	Drill 🗸 Cut 🗵					
Step	Description						illustration					
1	Ide	ntify the	grille 8	hardwar	e with pa	rts list.						
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.											
3	Place the grille shell face down on a work table. Cut the cross bars out of the upper and lower openings. (these are usually painted gray).Do not cut plastic mounting brackets in the center of the grille; there is one at the top and bottom. Cut around these, leaving an "L" shaped bracket. (see diagram below).											
4	shc	After cutting the center bars, place the billet insert in the openings above and below the bowtie. The front edge of the insert should be flush with the face of the grille shell. Note the brackets on each end of the billets. Mark the grille and drill 3/16 " holes. Fasten the billets to the shell using the #8 screws and flat clips.										
5	Ma	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.										
6	Re	Re-install the grille assembly back on the vehicle.										
7	Inst	Installation completed!!!										

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.