

## Grille Installation Instruction

Rev. 150116

Part# GR03HEJ4 Application 98~04 Chevy S-10 Stepside/Blazer LT - Criss-Cross Billet Grille

		Item	Part Name	QTY	Description	Item		Part Name	QTY	Description
Parts L	ist	1	Billet Grille	2	Stainless steel	3	Truss S	ocket Tapping Screws	6	8×3/4"
		2	U-Clip Nuts	6	8#					
Install Notes: Overlay  Replacement ×						Dril	1 \[	Cut ×		
Step	Description					illustration				
1	Ider	ntify the	grille & hardwa	are with	parts list.			병	ਚ ਚ	
2	Remove the grille from the truck by opening the hood and gently pulling on all our corners and in the center to release the retaining clips. Unplug the park lights and remove them.									
3	Center the billet grilles in the air intake pockets of the shell (five bar grille in the top. four bar grille in the bottom).					N/A				
4	Drill at the tab locations with a 1/8" drill bit and fasten with the screws and clips in the installation kit					N/A				
5	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.					N/A				
6	Reinstall the grille shell.					N/A				
7	Inst	allation	completed!!!			N/A				

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!